
# canfield connector

8510 Foxwood Court Youngstown, Ohio 44514 (330) 758-8299 Fax: (330) 758-8912 www.canfieldconnector.com

## AC MODEL CRT / AC SANDWICH CRT INSTALLATION GUIDE



#### Adjustment

#### AC Connector CRT

CRT

When first adjusting the connector CRT determine the approximate ON Time and OFF Time for your application. Adjust the screws CCW at least 20 full turns. This way it is sure to be adjusted to its lowest values (1 min. OFF, .25 sec. ON).

#### AC Sandwich CRT

Adjust the timer by turning the dimple in the adjustment wheel to correspond to the numerical number on the timer bezel.

Electrical	Characteristics
------------	-----------------

	Connector CRT		Sandwich CRT	
Parameter	Min.	Max.	Min.	Max.
Supply Voltage	24 VAC	240 VAC	12 VAC 120 VAC	120 VAC 240 VAC
Output Current Output Voltage	- = (Supply - 2) VAC	1 Amps = Supply	= (Supply - 2) VAC	1 Amps = Supply

### Environmental Characteristics

Temperature Range -20 °C +65 °C Connector Enclosure Designed to IP 65 / NEMA 4 Specifications.

